

WALL PUNCHER

Installation Guide for Ventex **Wall Puncher**

Installation

Please note: No screws or silicone are required for installation. This is a true two-part system.

- 1.** Through-wall protection for CL2 driven, low-voltage cables. Do not use with any high voltage circuits including GTO wire (neon installations).
- 2.** Install silicone grommet in 0.5" electrical knockout hole with beveled edge towards back of sign backer. Compression fit up to 3 mm backing.
- 3.** Ensure grommet is properly seated before proceeding – you will feel the grommet pop into place during **Step 2**.
- 4.** Install 15" pipe inside silicone grommet. It is recommended to twist the pipe while pushing at the same time to ease friction going in.
- 5.** Run low-voltage wire from channel letter, through pipe, and make electrical connections according to NEC guidelines.




Demo Video


To see a demo installation, please scan the QR code below.



Customer service and technical support

 ventextech.com

 803.794.8061

 3490 Venture Dr., San Angelo, TX 76905

